

#	DIST	ITEM
51	29'-3"	
50	28'-7"	
49	27'-11"	
48	27'-5"	
47	26'-7"	
46	35'-11"	5th ELECTRIC - 23 CIRCUITS
45	25'-3"	
44	24'-7"	
43	24'-2"	
42	23'-0"	Orchestra Shell #3
41	21'-5"	
40	20'-7"	
39	19'-9"	
38	18'-3"	4th ELECTRIC - 24 CIRCUITS
37	18'-7"	
36	27'-11"	
35	27'-3"	
34	26'-7"	
33	25'-11"	
32	25'-5"	
31	24'-7"	
30	23'-11"	
29	23'-5"	
28	22'-7"	
27	22'-2"	
26	21'-0"	Orchestra Shell #2
25	19'-5"	
24	18'-3"	
23	17'-2"	3rd ELECTRIC - 24 CIRCUITS
22	17'-3"	
21	16'-7"	
20	15'-11"	
19	15'-3"	
18	14'-7"	
17	13'-11"	
16	13'-5"	
15	12'-7"	
14	11'-11"	
13	11'-3"	2nd ELECTRIC - 24 CIRCUITS
12	10'-6.5"	
11	9'-10"	Orchestra Shell #1
10	7'-3"	
9	6'-7"	
8	5'-11"	
7	5'-3"	
6	4'-7"	
5	3'-11"	1st ELECTRIC - 30 CIRCUITS
4	2'-5"	False Stage Move Screen
3	2'-7"	Main Curtain - Full Stage Back
2	1'-5.5"	False Proscenium Legs
1	1'-4"	False Proscenium Heads
0	0'-5"	False Fire Curtain & Pocket

GOODS ON GREYED LINESETS ARE FIRED AND CANNOT BE CHANGED/MOVED
ELECTRIC PIPES ARE RACEWAYS
1st ELECTRIC CAN NOT TRIM ABOVE 26'-0"
FLY GALLERY @ 25'-6"

222 221 220 219 218 217 216 215 214 213 212 211 210 209 208 207 206 205 204 203 202 201 200 199

Dimmer 175-180
Dimmer 181-186
Dimmer 187-192
Dimmer 193-198

4 6-Circuit Mults can be run to 4th Electric or pulled to where needed

FLY RAIL CIRCUITS
Dimmer 1-6
Dimmer 273-275
Dimmer 266-268
Dimmer 259-261
Dimmer 247-250

LIGHTING POSITIONS
--Turn off class "ARCH-POS-ALL"
--Insert symbol "ARCH-LTG POSITIONS" into drawing @ 0,0
--Un-group
--Assign to desired Class

SL JUMP CIRCUITS
Dimmer 269-272
Dimmer 262-265
Dimmer 255-258
Dimmer 251-254

174 173 172 171 170 169 168 167 166 165 164 163 162 161 160 159 158 157 156 155 154 153 152 151

150 149 148 147 146 145 144 143 142 141 140 139 138 137 136 135 134 133 132 131 130 129 128 127

126 125 124 123 122 121 120 119 118 117 116 115 114 113 112 111 110 109 108 107 106 105 104 103 102 101 100 99 98 97

(MAINLY USEFUL FOR TOPLIGHT / HIGHSIDES)

HOUSE LEFT LADDER POSITION

HOUSE RIGHT LADDER POSITION

1 CAT LOW
Pipe Hangs below ceiling cloud piece

Dimmer 76-78
Dimmer 67-72
Dimmer 61-61
Dimmer 55-60
Dimmer 49-54
Dimmer 8
Dimmer 73-75

69 68 66 64 63 62 61 55 57 58 60 49 50 51

3 CAT LOW LIGHTING POSITION
Position is under spot booth

3 CAT LIGHTING POSITION

Dimmer 36
Dimmer 31-36
Dimmer 25-30
Dimmer 23-24
Dimmer 13-13
Dimmer 12
Dimmer 11
Dimmer 10
Dimmer 7
Dimmer 8
Dimmer 233-238
Dimmer 223-228

35 33 32 31 30 27 26 25 13 14 15 18 12 11 10 7 8

FOLLOWSPOT BOOTH

Balcony Rail Center Hanging Position

THE ALEXANDER KASSER THEATER Montclair State University

Lighting Ground Plan w/ Rep Units

Scale: 1/4" = 1'-0"

Drawn by: BW

- Dinner -
229-232

Drawn by: BW

